


Honeywell Configuration Bar Codes


Please scan the codes in the numbered order.

1. Enter Program Mode




999999

6. Configuration Code 4




816680

2. Recall Defaults




999998

7. Configuration Code 5




8183800

3. Configuration Code 1




80351500

8. Exit Program Mode




999999

4. Configuration Code 2



80451520

5. Configuration Code 3



81601520