

Wasp WWS650 Positrak Programming Sheet

[Link to Manual](#)



Factory Reset

Set Prefix to F7



Program
Mode



Prefix



8



B



Save



Exit

Set Suffix to F9 & Enter



Program
Mode



Suffix



8



D



Save



Exit